NEC SL Auto-dial buttons

CORTUM COMMUNICATIONS INC.

This is for programming unused buttons on your phone to call outside numbers. DO NOT PROGRAM AUTODIALS OVER LINE OR OTHER IMPORTANT BUTTONS!

1. Press “Menu” in LCD screen
2. Dial 51 on dialpad
3. Press “Select” in LCD
4. Press “Next” until you get to the button number you want to program. (the buttons are numbered starting from the top left)
5. Press “Select” in LCD
6. Dial 001 and press “Select” in LCD
7. Dial 9 and then enter the telephone number
8. Press HOLD

Repeat steps 4-8 for additional or press SPEAKER to exit.

JV 2/18