Programming Speed Dial One-touch Bin Buttons

AFFORDABLE TELEPHONE SYSTEMS

If your phone has a set of ten extra buttons below the LCD, you can store phone numbers on them for speed dialing.

Programming

1. With your phone hung up, press Pound (#) then 77
2. Press HOLD
3. Press the button you want to program
4. Press HOLD
5. Press Volume Up until “Group:90” appears
6. Press HOLD
7. Enter phone number (Ex: 18002929662)
8. Press HOLD
9. Enter the name (optional)
10. Press HOLD

repeat steps 3-10 for additional, or press SPEAKER to exit

Using

Press the One-Touch Button